

Grille Installation Instruction

| Part# | G | GR14HED48 C/J/S Applicat | | ation | For 2004-2010 Infiniti QX56 Not Good For Speed Sensor Package | | | | | | | |
|--|--|--|--------|--------|--|-----------------|--------------|------|-------------|-----|-------------|--|
| | | ltem | Part N | lame | QTY | TY Descriptio | | Item | Part Name | QTY | Description | |
| Parts Li | ist | st 1 Billet G | | le | 1 | Stainless steel | | 3 | U-Clip Nuts | 4 | 8# | |
| | | 2 | Screws | Screws | | #8×2″ | | 4 | "J" Hook | 4 | | |
| Install Notes: Overlay \checkmark Replacement \times Drill \times Cut \times | | | | | | | | | | | | |
| Step | Description | | | | | | illustration | | | | | |
| 1 | Identify the grille & hardware with parts list. | | | | | | | | | | | |
| 2 | Do not install this bumper billet insert if you vehicle is equipped with speed sensing cruse control. Open the hood of the vehicle. | | | | | | | | | | | |
| 3 | Test fit the bumper insert into the opening. Remove the grille. Install the u-clip nuts onto the "J" hook tabs supplied in the hardware. | | | | | | | | | | | |
| 4 | Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell. | | | | | | | | | | | |
| 5 | | Insert the screws into the tabs on the billet insert (noted by the arrow in the diagram).Start to thread the "J" hook tabs onto the screws from behind the billet grille. | | | | | | | | | | |
| 6 | wrap | Re-center the bumper billet insert over the plastic vertical bars in the bumper opening. Reach from behind the bumper and wrap the "J" hook tabs around the plastic bars as shown here in the picture. Use a Phillips screwdriver to tighten the hardware. | | | | | | | | | | |
| 7 | Insta | Installation completed!!! | | | | | | | | | | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!