

## Grille Installation Instruction

Rev. 150116

Part# GR14HFD63H Application 07~08 Nissan Maxima - Billet Grille

Description Item

		Item	Part Name	QTY	Description	n   Item	Part Name	QTY	Description
Parts L	ist	1	Billet Grille	1	Aluminum	3	Extension Brack	kets 2	8# × 1 "
		2	U-Nuts	2	8#	4	Screws (#6 Hea	ad) 2	
Install Notes: Overlay						Drill	/ Cut	×	
Step	Description					illustration			
1	Identify the grille & hardware with parts list.								
2	Open the hood and remove the factory plastic radiator cover and grille assembly. Now remove the factory grille shell; use a small screwdriver to pull the center from each fastener. Do not discard the fasteners. Release the four molded clips along the bottom of the grille.								
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille.Be sure the bolts are through the OEM grille shell.								
4	Slide the two u-nuts onto the bent end of extension brackets. These attach to the tabs along the top of the grille. Use the Phillips screws to secure them. The grille has two clips attached to the bottom of the grille. They slide into the factory mounting holes. Center the grille; slide the lower clips in place. The extension brackets align to the factory mounts. Use the factory fasteners to secure the brackets.								
5	Carefully check the hood clearance to the grille. Loosen the fasteners and adjust the bracket and (or) billet if needed. The radiator cover can be re-installed; two 1/4" holes must be drilled into the cover. Align these holes with the factory mounting holes. Secure the radiator cover with two of the factory fasteners.								
6	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.					N/A			
7	Reinstall the black plastic cover which was removed in step 2.					N/A			
8	Installation completed!!! N/A								

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!