

## PATENT PRODUCT Grille Installation Instruction

Rev. 20210401

	F	Part#	N86483C&J&S	Application	For 2007-2011 Nissan Versa
--	---	-------	-------------	-------------	----------------------------

Parts List         #1         Billet Grille         1         Stainless Steel         #4         Allen Head Bolts         4         1           #2         Speed Clips         2         #5         Powder Coated Brackets         2           #3         Screws         2         8#         #6         K-Lock Nuts         4	1"					
#2 Speed Clips 2 #5 Powder Coated Brackets 2						
#3 Screws 2 8# #6 K-Lock Nuts 4						
Install Notes: Overlay × Replacement √ Drill √ Cut √						
Step Description illustration	illustration					
1 Identify the grille & hardware with parts list.	Identify the grille & hardware with parts list.					
Tape off the around the center section of the bumper just behind where the Nissan logo was located on the fashell.	Tape off the around the center section of the bumper just behind where the Nissan logo was located on the factory grille shell.					
3 Using a die grinder remove the lower tab from the bumper center section.	Using a die grinder remove the lower tab from the bumper center section.					
Tape off around the bottom of the bumper center section and mark a line where the center section and bumper meet						
Use a die grinder to carefully cut along the line made in <b>Step 4</b> .						
Once you have separated the bumper from the center section remove the center section from the vehicle.						
7 Center the billet grille into the factory grille shell opening and mark and drill the lower mounting holes.	Center the billet grille into the factory grille shell opening and mark and drill the lower mounting holes.					
8 Secure the lower portion of the billet grille to the vehicle using the #8 Screws and Speed Clips.	Secure the lower portion of the billet grille to the vehicle using the #8 Screws and Speed Clips.					
Loosely attach the Powder Coated Brackets to the upper mounts of the billet grille using the Allen Head Bolts and K-Lock Nuts.						
Line the Powder Coated Brackets up with factory mounting points and hold in place using the Allen Head Bolts and K-Lock Nuts.						
Make sure the insert is centered and tighten the hardware.						
Reinstall the plastic shroud with the fasteners removed.	Reinstall the plastic shroud with the fasteners removed.					
13 Installation completed.	Installation completed.					

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!