




Part#	GR14HFD85H	Application	03~08 Nissan Murano - Billet Grille
-------	------------	-------------	-------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	4	Powder Coated L-Brackets	4	
	2	Allen Head Bolts	4		5	Powder Coated Flat Brackets	2	
	3	K-Lock Nuts	8	10-24	6	Fully Threaded Studs	4	1 1/4"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the factory grille shell and the plastic filler panel from the vehicle.	
3	Install the fully threaded studs into the threaded mounting holes on the back bottom side of the billet grille.	
4	Tape off the area around the factory grille shell opening to protect it during the installation process.	 
5	Using a die grinder carefully remove the lip from the top side of the bumper. Figure 1 & 2.	
6	Once the lip is removed from the bumper it may be necessary to smooth out the rough edges left after cutting.	
7	Center the billet grille into the factory grille shell opening.	
8	Place the powder coated L-brackets over the fully threaded studs so that the L portion is hooked over the backside of the bumper and hold in place using the k-lock nuts.	
9	Attach the powder coated flat brackets to the upper mounts on the billet grille using the Allen head bolts and k-lock nuts.	
10	Mark and drill the mounting holes into the core support where the powder coated brackets line up.	
11	Once the mounting holes have been drilled attach the upper powder coated brackets to the vehicle using the Allen head bolts and k-lock nuts.	
12	Re-center the billet grille to your liking and secure all hardware.	
13	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!