

## **PATENT PRODUCT**Grille Installation Instruction

Rev. 20220101

AUTO PARTS SPECIALIST INC. SITTING III STATISTICALI II S										
Part#	N	86566	C&J&S	Applicat	ion	For 2007-2009 N	ssan Altin	na Coupe		
		Item		art Name	QTY	Description	Item	Part Name	QTY	Description
Parts L	ict	#1	Billet G	Grille	1	Stainless Steel	#4	Kep Nuts	8	6-32
raits L	ıσι	#2	Studs		8	6-32X2.5"	#5	Flange Brackets	8	2"
		#3	Washe	ers	8					
Install Notes: Overlay × Replacement √ Drill × Cut ×										
Step				Description		illustration				
1	Identify the grille & hardware with parts list.									
2	Use a slotted screwdriver to remove eight plastic fasteners on top of the bumper cover (above the grille); pull the center from each fastener (1). The upper corners of the bumper cover and grille are secured to the core support with a retaining clip. Pull the bumper cover forward on one end; from behind the grille, use a slotted screwdriver to depress the clip (2&3). Repeat on other side.									
3	Remove the air intake shield in front of the intake (4). Do not remove the intake behind the core support. Two plastic fasteners secure the shield. Remove the shield (5).									
4	Pull the top of the grille assembly forward. Use a finger or screwdriver to depress the remaining molded clips along the top and bottom of the grille (6). Removal of a lower clip is shown in diagram (6). There are four clips on top and four on the bottom. Now remove the factory grille from the front of the bumper.									
5	Center the grille into the bumper opening (7). Thread a stud in each nut welded to the grille. The studs align to the factory grille slots. From behind the grille; install a flange bracket and two nuts. Make sure the grille is centered; tighten the hardware until the grille is held firmly in place. Loosen the hardware and adjust if needed.									
6	Reinstall the air intake shield. Install the retaining fasteners on top of the bumper cover.									
7	Installation completed.									
4		6 - S		5			3		7	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!