


Part#	GR14HFF38 A/H	Application	For 2009-2014 Nissan Cube Not For Krom edition
-------	------------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Screws	6	8#
	2	Speed Clips	6		4	Powder Coated L-Brackets	2	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Attach the lower portion of the billet grille to the vehicle using the supplied clips and screws.	
4	Loosely attach the powder coated L-brackets to the billet grille using the #8 screws and speed clips.	
5	Line up the L-brackets with the factory mounting points and secure using the supplied clips and screws.	
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!