

## Grille Installation Instruction

Rev. 200801

Part#	GR14HGI65A		Application		For 20	For 2005~2006 Nissan Alt		ima	
	Item	Part Name	QTY	Desc	ription	Item	Part Name	QTY	Description
	1	Billet Grille insert	2	Aluminu	ım	6	Kep Nuts	6	10-24
Parts	2	Slotted Studs	2	10-24×2	2"	7	Extension Brackets	2	/
List	3 Button Head Screws		s 4	10-24×1″		8	Upper Brackets	2	/
	4 Stud 4		6#-1.5″		9	Tab	4		
	5	Lock Nut	4	6#					
Install Notes: Overlay $\times$ Replacement $$ Drill $\times$ Cut $\times$							Cut ×		
Step	Description				illustration				
1	Identify the grille & hardware with parts list.								
		od, remove the black rille shell.	plastic cov	ver (on top	of OEM gr	ille / front	panel) from vehicle. This	will allow a	access to the rea
3	of the g Start w extens	rille shell. vith the main grille.	Attach the	ne fully th billet gri	nreaded s lle, using	tuds to th	panel) from vehicle. This ne back side of the bil ded hardware. Do not	let grille.	Next attach th
3	of the g Start w extens	rille shell. vith the main grille. ion brackets to the	Attach the	ne fully th billet gri	nreaded s lle, using	tuds to th	ne back side of the bil	let grille.	Next attach th
	of the g Start w extens this tim Place I	rille shell. vith the main grille. ion brackets to the ne. Attach the lower	Attach the top of the brackets	he fully the billet gritter to the billet gr	areaded s lle, using let grille.	tuds to the provid	ne back side of the bil	let grille. tighten do	Next attach th own hardware a

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!



## Grille Installation Instruction

Part#		GR14HGI65A	Application	For 2005~2006 Nissan Altima				
8	Move on to the bumper grille. Secure the stud to the threaded holes on the rear of the grille.							
9	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.							
10	Secure grille using the lock nuts and tads from the back side of the OEM grille shell.							
11	Tighten down all hardware at this time.							
12	Reinstall the black plastic cover which was removed in step 2.							
13	Installation completed!!!							

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during

installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!