

Grille Installation Instruction

Part#	GR14HGI65J Applica		ation 2005-2006 Nissan Altima						
	Item	Part N	lame	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	1 Billet Grille insert		2	Stainless steel	6	Kep Nuts	4	10-24
	2	2 Slotted Studs		2	6-32×2″	7	Extension Brackets	2	/
	3	3 Button Head Screws		4	10-24×1″	8	Upper Brackets	2	/
	4	4 Flat Nuts		2	6-32	9	Lock Nut	4	6#
	5	5 Stud		4	6#-1.5″	10	Tab	4	1
Install N	lotes:	Overlay	× Re	placen	nent 🗸 Dri		Cut 🛛		
Step	Description				illustration				
1	Identify the grille & hardware with parts list.								
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.								
3	Start with the upper section. Attach the fully threaded studs to the back side of the billet grille Next attach the extension brackets to the top of the billet grille, using the provided hardware. Do not tighter down hardware at this time. Attach the lower brackets to the billet grille.								
			A				1 10		
4	the spacing is equal on each side of the grille as well as the billet grille being even with the hood line. Once the grille is in place, attach the upper brackets to the vehicle. As well secure the lower brackets.								
5	Once to bracke	acing is equ the grille is in ets to the vel	al on each	tach the	f the grille as well a		aking sure that all billet et grille being even with		
	Once t bracke lower l	acing is equ the grille is in ets to the ver brackets.	al on each n place, at nicle. As w	tach the	f the grille as well a e upper ure the	s the bill		n the hoo	
5	Once to bracke lower l	acing is equ the grille is in ets to the ver brackets. on to the low	al on each n place, at nicle. As w ver sectior	tach thur rell sect	f the grille as well a e upper ure the ure the stud to the th	s the bill	et grille being even with	e grille.	d line.
5	Once to bracke lower l Move	acing is equ the grille is in ets to the ver brackets. on to the low r the grille in	al on each n place, at nicle. As w ver section to the ope	tach the rell sect	f the grille as well a e upper ure the ure the stud to the the the factory grille sh	s the bill nreaded ell. Be s	et grille being even with	e grille.	d line.
5 6 7	Once to bracke lower l Move Center Secure	acing is equ the grille is in ets to the ver brackets. on to the low r the grille in e grille using	al on each n place, at nicle. As w ver section to the ope the lock r	tach three the second s	f the grille as well a e upper ure the ure the stud to the the the factory grille sh	s the bill nreaded ell. Be s k side of	et grille being even with	e grille.	d line.
5 6 7 8	Once to bracke lower l Move Center Secure Make	acing is equ the grille is in ets to the ver brackets. on to the low r the grille in e grille using sure the grill	al on each n place, at nicle. As w ver section to the ope the lock r e is cente	tach thr rell sect n. Secu ning of nuts and	f the grille as well a e upper ure the ure the stud to the the the factory grille sh d tads from the bac	s the bill nreaded ell. Be s k side of ers.	et grille being even with	e grille.	d line.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!