




Grille Installation Instruction

Rev. 180801

Part#	GR16GGB14T/H	Application	For 2008-2009 Pontiac G8
-------	---------------------	-------------	---------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	2	Stainless steel	3	Screws	8	6-32X1 "
	2	Flat tabs	8		4	K-Lock Nuts	8	6-32

Install Notes: Overlay	<input checked="" type="checkbox"/>	Replacement	<input type="checkbox"/>	Drill	<input type="checkbox"/>	Cut	<input type="checkbox"/>
------------------------	-------------------------------------	-------------	--------------------------	-------	--------------------------	-----	--------------------------

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.	
4	Insert a screw in each nut welded to the grille. From the rear, place a flat tab on each screw. Now thread a lock nut on each screw.	
5	Make sure the grille is centered and tighten the hardware.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed.	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!