



PATENT PRODUCT Grille Installation Instruction

Rev. 20201201

Part#	P85158C&J&S	Application	For 2005-2009 Pontiac G6 Not For GXP Model
--------------	-------------	--------------------	--

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	#1	Billet Grille	1	Stainless Steel	#3	Screws	6	8# x 1"
	#2	U-Clip Nuts	6	8#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.	
3	Center the billet grille into the opening of the factory grille shell. Secure the Screws to the threaded holes on the front of the grille. Be sure the Screws are through the OEM grille shell. Mark and drill (6) holes on the OEM grille shell.	
4	Secure billet grille using the U-Clip Nuts from the back side of the OEM grille shell.	
5	Make sure the insert is centered and tighten the hardware.	
6	Reinstall the plastic shroud with the fasteners removed in Step 2.	
7	Installation completed.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!