

## Grille Installation Instruction

Part#	GR16HEH06A/H			Application	For 20	For 2004-2006 Pontiac GTO						
		Item	Part Na	me QTY	Description		Item	em Part Name		QTY	Description	
Parts L	ist	1	Billet Grille	2	Aluminum		3	Bolts		4	6-32 ×2″	
		2 U-Nuts		4	6#		4	J Hooks		4		
Install N	Note	otes: Overlay 🛛 Replacement 🔿					Drill × Cut ×					
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Open the hood and remove the bolts along the top of the bumper cover. Remove the plastic fasteners along the top. Pull the bumper cover forward and remove the metal clips retaining the honeycomb inserts on top (1).Pull the inserts forward (2) and remove the clip on the bottom .											
3	Hold the billet insert up to the opening of the factory shell, and make sure that it is centered in the grille shell.											
4	<ul> <li>a. Slide the U-nuts onto the J hooks. Center each of the inserts and fasten using the J hook assembly(3). Make sure the installation is correct, as shown right Fig.</li> <li>b. Place screws through the welded aluminum tabs on the grille, and attach a J hook on backside of factory grille.</li> <li>c. Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.</li> </ul>											
5	Re-	Re-install the fasteners securing the bumper cover to the vehicle.										
6	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!