

## Grille Installation Instruction

Rev. 180601

Part# GR18FF0	C79A/H Application	For 2015-2018 Chrysler 300C/300S WITHOUT ADAPTOR CONTROL Lower Bumper
---------------	--------------------	---

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	1	Aluminum	3	Screws	4	6-32X1.5"
	2	Toggle Nuts	4	6-32				

Install Notes: Overlay	$\sqrt{}$	Replacement	×	Drill	×	Cut	×	
------------------------	-----------	-------------	---	-------	---	-----	---	--

Install	Notes: Overlay 📉 Replacement 🔀	Drill   ×   Cut   ×				
Step	Description	illustration				
1	Identify the grille & hardware with parts list.					
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.					
3	Center the grille into the opening of the factory grille shell. Secure the screw to the threaded holes on the front of the grille.Be sure the screws are through the OEM grille shell.					
4	Secure the grille using the toggle nut from the back side of the OEM grille shell.	AND THE PROPERTY OF THE PROPER				
5	Make sure the billet grille is centered and tighten the fasteners.					
6	Reinstall the black plastic cover which was removed in step 2.					
7	Installation completed!!!					

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!