


| | | | |
|-------|------------|-------------|--|
| Part# | GR18GEC10T | Application | For 2001-2003 Chrysler Sebring Sedan Only |
|-------|------------|-------------|--|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|-------------|-----|-----------------|------|----------------|-----|---------------|
| | 1 | Mesh Grille | 1 | Stainless steel | 3 | Screws | 6 | 6-32 × 1 1/2" |
| | 2 | K-Lock Nuts | 6 | 6-32 | 4 | Two -Hole Tabs | 3 | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|---|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | N/A |
| 3 | Center the grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell. | N/A |
| 4 | Thread a screw in each nut welded to the grille. From the rear, place a two-hole tab on two screws. Now thread a nut on each screw. | N/A |
| 5 | Reinstall the black plastic cover which was removed in step 2. | N/A |
| 6 | Installation completed!!! | N/A |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!