

Grille Installation Instruction

Part#								015-2018 Chrysler 300C/300S WITHOUT ADAPTOR ROL Lower Bumper						
		Item	m Part Nam		ne QTY		escri	ption	Item	em Part Nam		QTY	Description	
Parts L	ist	1	Mesh Grille		1	Stai	inless	steel	3	Flat	it Tab	6		
		2 Hex Flange			6	0.13	0.138-32UNC							
Install N	Note	es: 0∖	verlay 🗸	Re	Replaceme		×	Dri	ill 🗌	√ Cut		×		
Step	Description								illustration					
1	Identify the grille & hardware with parts list.													
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.													
3	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell. You need mark and drill 2 holes.													
4	Secure the grille using the flat tab and hex flange nut from the back side of the OEM grille shell.													
5	Ма	Make sure the billet grille is centered and tighten the fasteners.												
6	Reinstall the black plastic cover which was removed in step 2.													
7	Installation completed!!!													

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!