

Grille Installation Instruction

Rev. 180501

Part#						15-2018 Chrysler 300C/300S WITH ADAPTOR CONTROL Bumper				
		Item	Part Nam	e QTY	Description		Item	Part Name	QTY	Description
Parts Li	ist	1	Mesh Grille	2	Stainless steel		3	Flat Tab	8	
		2	Hex Flange I	Nut 8	0.138-32U	INC				
Install Notes: Overlay Replacement								√ Cut	×	
Step	Description					illustration				
1	Identify the grille & hardware with parts list.									
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.									
3	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell. You need mark and drill 4 holes.									
4	Secure the grille using the flat tab and hex flange nut from the back side of the OEM grille shell.									
5	Make sure the billet grille is centered and tighten the fasteners.									
6	Reinstall the black plastic cover which was removed in step 2.									
7	Inst	allation	completed!!!				<u> </u>			

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!