



Part#	GR18GFI05T	Application	2006-2010 Chrysler PT Cruiser
-------	------------	-------------	-------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	2	Stainless steel	2	self-tapping screws	16	/

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Remove the plastic electroplating article decoration	N/A
4	Secure self-tapping screws to the threaded holes on the rear of the grille.	N/A
5	Center the grille into the opening of the factory grille shell. Be sure the self-tapping screws are through the OEM grille shell.	N/A
6	Make sure the grille is centered and tighten the fasteners.	N/A
7	Reinstall the black plastic cover which was removed in step 1.	N/A
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!