

Part#	GR18HGG29A	Application	For 2000-2005 Chrysler PT Cruiser
-------	------------	-------------	-----------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Aluminum	2	Screws	4	#8×3/4"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Start with the main grille. Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Center the billet grille into the opening. Make sure the alignment tab on the bottom is positioned behind the bumper cover. Use the factory fastener to secure the lower mounting bracket to the factory mount. (Do not tighten this fastener yet).	
4	Close the hood and adjust the billet insert. Hold the billet insert firmly in place and open the hood. Drill a 1/8"hole at each mounting bracket on top. Use the screws provided to secure the top mounting brackets. Tighten all the mounting hardware.	
	<p>Move on to the bumper grille. Center the billet insert over the opening in the air dam. Mark the brackets to the factory grille.</p> <p>Drill a 1/8"hole at each mark. Re position the billet insert over the opening. Use the #8 screws to secure the billet insert to the opening.</p>	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;"> <p>Mark & Drill holes onto the OEM grille according to the weld tab holes position of billet grille. And then, secure the billet grille on the OEM grille with the screws.</p> </div>

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 200801

Part#	GR18HGG29A	Application	For 2000-2005 Chrysler PT Cruiser
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.		
7	Reinstall the black plastic cover which was removed in Step 2.		
8	Installation completed!!!		

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!