




# Grille Installation Instruction

Rev. 180301

Part#	GR19HGF12A/H	Application	For 2006-2007 Saturn Vue Not For Red Line
-------	--------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Truss Socket Tapping Screws	2	8-32x1"
	2	Flat Nuts	2	8-32				

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the two rubber hood stops that retain the top edge of the factory grille.	
3	Unclip the factory grille and remove it from the vehicle.	
4	Unclip the black center section of the grille from the chrome trim. Gently tapping the backside of the plastic tabs with a small hammer should be enough to push them through.	
5	Center the billet grille in the chrome trim and mark where the two lower mounting tabs meet the bottom edge of the chrome trim.	
6	Remove the grille and drill two 1/8" holes on your marks.	
7	Replace the grille and attach it to the chrome trim loosely with the two supplied screws. <b>***NOTE***</b> the screws may be a very tight fit going through the bars of the grille. If necessary, use a rubber or plastic coated tool to gently spread the bars of the grille near the screw holes while you slide the screws into the grille, and then install it onto the chrome trim.	
8	Re-install the chrome trim with the attached billet grille onto the vehicle and secure the top mounting brackets with the factory rubber hood stops.	
9	Tighten lower mounting screws until snug.	
10	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!