




| | | | |
|-------|--------------|-------------|----------------------------|
| Part# | GR20FEC81A/H | Application | For 2005-2006 Toyota Camry |
|-------|--------------|-------------|----------------------------|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-------------|------|-------------------|-----|-------------|
| | 1 | Billet Grille | 1 | Aluminum | 3 | Truss Head Screws | 3 | 6# - 32x2" |
| | 2 | Flat Tabs | 3 | | 4 | Flange Nuts | 3 | 6# - 32 |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|---|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation. | |
| 3 | Position the Billet Grille onto grille shell cavity. | |
| 4 | Loosely attach the Billet Grille by holding the Flat Tabs behind factory grille shell and inserting the Screws (from the front) through the Billet Grille holes and Flat Tabs, secure them with Flange Nuts provided. |  |
| 5 | Once the Billet Grille is loosely attached, center it and tighten all Screws at the same rate. | |
| 6 | Reinstall the black plastic cover which was removed in step 2. | |
| 7 | Installation completed!!! |  |

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!