



PATENT PRODUCT


Grille Installation Instruction

Rev. 190101

Part#	GR20FED49J	<i>Application</i>	For 2006-2009 Toyota Prius With Fog Light
--------------	------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	4	Truss Head Screws	6	6-32×1.5"
	2	Nylon Lock Nuts	6	6-32	5	“ U ” Powder Coated Brackets	6	
	3	Washers	6	6#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood of the vehicle. Remove the upper motor cover between the grille and core support. Remove the upper grille clips and hood stops. Insert the new grille into the factory bumper opening.	
3	Place the billet in the factory bumper opening. Insert a screw in each bracket welded to the rear of the billet grille. Install a bracket so the bent edges face forward. These brackets wrap around the factory plastic cross bar and hold the billet in place.	
4	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
5	Reinstall the upper motor cover which was removed in step 2.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!