


|       |            |             |  |
|-------|------------|-------------|--|
| Part# | GR20FED71A | Application | 06~09 Toyota Prius Low Bumper Fog Lights Covered |
|-------|------------|-------------|--|

| Parts List | Item | Part Name     | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-------------|------|-----------|-----|-------------|
|            | 1    | Billet Grille | 1   | Aluminum    | 3    | Screws    | 6   | 8# × 2 "    |
|            | 2    | U-Clip Nuts   | 6   | 8#          | 4    | Flat tabs | 6   |             |

Install Notes: Overlay  Replacement  Drill  Cut

| Step | Description  | illustration   |
|------|--|--|
| 1    | Identify the grille & hardware with parts list.  |  |
| 2    | Remove grilles from box and test fit the grilles first to identify the top grille from the bottom grille. They will only fit in one direction correctly.   | N/A  |
| 3    | Place one screw through each of the welded tabs on the billet grille.  | N/A  |
| 4    | Place a U-clip nut over each of the holes on the single hole flat tab.   | N/A  |
| 5    | Where the screws come through the grille shell, place a tab in align with the screw and tighten. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. DO NOT OVER TIGHTEN SCREWS. | N/A  |
| 6    | Reinstall the black plastic cover which was removed in step 2.   | N/A  |
| 7    | Installation completed!!!  | N/A  |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!