

PATENT PRODUCT Grille Installation Instruction

Rev. 20211201

Part#	Te	6329	C&J&S	Applicatio	on F	or 201	6-2021 Toyot	a Taco	ma SR/ SR5			
		Item	Part Name		QTY De		scription	ltem #3	Part Name Clip Nuts	QTY 6	Description 8#	
Parts Li			Billet Grille		1	Stainle	s Steel					
	#2 Screws			6	6 8#-2"		#4	Tabs	6			
Install Notes: Overlay \checkmark Replacement \times Drill \times Cut \times												
Step	Description					illustration						
1	Identify the grille & hardware with parts list.											
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.											
3	Install the clip nuts onto the tabs as shown.											
4	Thread a screw in each nut welded to the grille. Secure billet grille using the clip nuts and tabs from the back side of the grille shell.											
							(6) Screws (6) Clip Nu (6) Tabs					
5	Ma	Make sure the insert is centered and tighten the hardware.										
6	Reinstall the plastic shroud with the fasteners removed in Step 2.											
7	Installation completed.											

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!