

## Grille Installation Instruction

Rev. 180301

Part#	GR20FFD56A/H	Application	For 2005-2010 Toyota Tacoma 1 PC Center & 2 PCS For Side Holes
-------	--------------	-------------	--

		Item Part Name		QTY	QTY Description		n	Item	Part Name			QTY	Description	
	-	1	Billet Grille		3	Aluminum			5	Truss Head Screws		ews	2	M4×30
Parts L	ist	2	"Z" Tabs		8				6	Truss Head Screws		ews	2	M4×20
		3	Flat Tabs		2				7	Truss Head Screws		ews	2	M4×35
		4	Flange Nuts		10				8	Truss Head Screws		ews	4	M4×50
Install Notes: Overlay  Replacement							×	C	Prill	V	Cut	×		
Step	Description							illustration						
1	Identify the grille & hardware with parts list.													
2	Optional (for vehicles with black plastic cover under hood). Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.													
3	Carefully position billet grille over the grille shell.													
4	Hold Metal Bracket behind opening of grille shell and insert Phillips Machine Screw (from the front) through the Billet Grille hole and Metal Bracket; secure it with clips provided.													
	FO	R SIDE	BILLE	T GRILL	.ES:									
	Carefully position left section of billet grilles over the left upper opening of the grille shell.													
5	Drill holes on the grille shell using 1/8" bit.													
	Secure the billet grille on the grille shell by using the screws provided.													
	Re	peat th	e proce	ss on the	e right up	per ope	ning o	f the	grille sh	nell.				
6	Make sure the billet grille is centered and tighten the fasteners.													
7	Reinstall the black plastic cover which was removed in step 2.													
8	Installation completed!!!													

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!