

## **PATENT PRODUCT**

## Grille Installation Instruction

Rev. 190601 For 2005-2011 Toyota Tacoma TRD Sport Hood

Part#	G	R20F	FE01C/J/S	Appli	cation Gr		2011	Toyota Ta	acoma TI	<b>к</b> D Sр	ort Hood	
	Item		Part Name	QTY	Descriptio	n Iter	n	Part Name		QTY	Description	
Parts Li	ist	t 1 Billet Grille		1	Stainless steel		Trus	Truss Head Tapping Screw			8# × 1 ″	
		2	Flat Nut	2	8#							
Install N	Note	es: O	verlay   √	Repla	cement	Dı	ill ×	Cut	×			
Step	Description						illustration					
1	Identify the grille & hardware with parts list.						:		-	n	=	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.											
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.											
4	Secure billet grille using the nuts from the back side of the OEM grille shell.											
5	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.											
6	Reinstall the black plastic cover which was removed in step 2.											
7	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!