

Grille Installation Instruction

Rev. 180901

Part#	GR20FFE47A/H Applie		Applic	ation	For 2008-2	For 2008-2010 Toyota Highlander Hybrid			
	Item	Part Na	me	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille		1	Aluminum	3	U-Clip Nuts	6	8#
	2	2 Screws		6	8# ×2"	4	Flange Tabs	6	
Install Notes: Overlay V Replacement X Drill X Cut X									
Step	Description					illustration			
1	Identify t	he grille & hardv	vare with	parts lis	t.				
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.								
3	Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.								
4	Place one screw through each of the welded tabs on the billet grille.								
5	Place a U-clip nut over the holes on the flat tabs.								
6	Place a tab behind the grille shell in line with were the screw comes through. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center.								
7	Make sure the grille is centered and tighten the fasteners, but do not over tighten.								
8	Reinstall the black plastic cover which was removed in step 2.								
9	Installation completed!!!								

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!