

Grille Installation Instruction

Rev. 150116

Part#	GR20HEC6 5C	Application	01~04 Toyota Tacoma (Center Section Only)
-------	----------------	-------------	---------------------------------------------

		Item	Part Nan	ne QTY	Descrip	tion	Item	Part Name	QTY	Description		
Parts List		1 Billet Grille		1	1 Stainless steel		3	Hex Bolts	7	1/4" -20x3/4"		
		2	2 Mounting Clip		1		4	Kep Nuts	7	1/4" -20		
Install Notes: Overlay X Replacement √							Orill \	Cut √				
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. Remove the factory grille shell from the vehicle.											
3	nine off grille	verticathe ma	lle shell on a all bars out of ain attachment Cut the horizo	the grille shel t mounts on	I. Do not cut backside of	-	REAR VIEW OF GRILLE SHELL OUT OFF AT DOTTED LINES O O O O O O O O O O O O O					
4	Center billet grille in grille shell and mark locations of mounting holes. Drill 1/4" holes in grille shell on marks.											
5	(Optional) Paint the inner rim of the grille shell with flat black paint.					_	DO NOT CUT OFF MAIN ATTACHMENT MOUNTSI					
6	Attach billet grille to grille shell with six 1/4" bolts and kep nuts.						FINISHED GRILLE MOUNT					
7	Install grille shell back on truck.											
8	Place safety release lever extension as shown in picture on next page. Mark location and drill 1/4" hole through lever. Fasten extension with 1/4-20 bolt and kep nut. Make sure the safety release lever extension has at least 1/8" clearance. Close hood and check operation of safety release.											
9	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.											
10		nstall th tep 2.	e black plastic	cover which v	vas removed							
11	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!