




Grille Installation Instruction

Rev. 190801

Part#	GR20HED26A/H	Application	For 2003-2008 Toyota Matrix
-------	---------------------	-------------	------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Truss Head Screws	4	6-32×1.5"
	2	Washers	4		4	Nylon Lock Nuts	4	6#

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the factory grille. Lighter colors will show through the bars of the billet insert. A coat of matt black spray paint can be applied to the inner mounting surface for a cleaner appearance. Lightly scuff the paint and apply a light coat of black spry paint to the inside lip of the hood (the sheet-metal mounting surface normally hidden behind the factory grille).Let the paint dry. Be sure to mask the vehicle off to prevent overspray.	
3	Center the insert on the hood. Align the tabs to the factory mounting holes. It may be necessary to drill new holes or elongate the factory holes using a drill bit of file.	
4	Insert a screw from the front; Place a washer on the rear and thread a nut.	
5	Make sure the insert is centered. Then tighten the hardware.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!