

PATENT PRODUCT

Grille Installation Instruction

Rev. 200801

Part#	GR20HGG42S			Application		2005-2010 Toyota Tacoma TRD Sport								
	Item		Part Name		QTY	QTY Descrip		n Item		Part Name			QTY	Description
	1		Billet Grille		5	Stainless ste		el 5	Trus	Truss Head Tapping Screws			s 4	8#×3/4"
Parts Li	ist 2		Clip Nuts		8	8#		6	Trus	Truss Head Tapping Screws			s 4	8#×1″
	3		Flat Nut		2	8#		7	"J" ⊢	"J" Hook Tabs			2	
		4	Screws		4	8#×1 ″								
Install N	Notes: Overlay X		×	Replacement		t	√ [orill	\checkmark	Cut	\checkmark			
Step	Description					illustration								
1	Identify the grille & hardware with parts list.													
	Start with the hood grille. Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.													
	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.													
	Secure billet grille using the nuts from the back side of the OEM grille shell. Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.													
5	Continue to the main grille. Remove the plastic clips that are located on the top of the grille shell (Fig 1).													
6	Remove the center bolt from the grille shell as shown (Fig 2).													
7	Remove the grille shell from the vehicle simply pull up on the grille and it will unclip from the vehicle (Fig 3).													
$\left \begin{array}{c} \hline \\ \hline $														
8	A close look at the grille shell clip (Fig 4).													
9	A close look at where the grille shell clip inserts into (Fig 5).													

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



PATENT PRODUCT Grille Installation Instruction

Rev. 200801

Part#	GR20HGG42S	Application	2005-2010 Toyota Tacoma TRD Sport							
10	10 We will need to cut out the factory grille center using an air saw works great but a hand saw will do. (Fig 6).									
		Fig 4	$\left \begin{array}{c} \hline \\ \hline $							
11	Removing the grille cente	r (Fig 7).								
12	12 Insert the new grille insert into the factory grille shell. (Fig 8).									
13	13 While holding grille insert in place drill for the mounting screws. (Fig 9).									
		Fig 7	$\left \begin{array}{c} \hline \\ \hline $							
14	Fasten the grille in place whardware (Fig 10).	with the supplied	Fig 10							

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



PATENT PRODUCT

Grille Installation Instruction

Τ

Rev. 200801

Part#	# GR20HGG42S Application 2005-2010 Toyota Tacoma TRD Sport								
15	Move on to the bumper g the end of the "J" hook opening with the shorte welded to the rear of th From the front, insert a billet insert. Start to thr hook tabs as show belo over the opening. Wrap over the factory cross b	tabs. Center the est bar on top. No e insert. Remove screw into each t ead both screws i ow. Now place the o the ends of the "	billet over the te the tabs the insert. top tab on the nto the "J" e billet insert	(faateree					
16	Make sure the grille is centered and tighten the fasteners.								
17	Reinstall the black plastic cover which was removed in step 2.								
18	Installation completed!!!								

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!