

Grille Installation Instruction

Rev. 191001

Part#	GR21GGB01T/H	Application	For 2003-2005 Mitsubishi Eclipse
-------	--------------	-------------	----------------------------------

	Item		Part Name		QTY	De	escription		tem	Part Name		QTY	Description	
Parts Li	ist	1	Mesh Grille		5	Stainless steel			3	Screws		7	8×5/8"	
		2	Plat Nuts		3 8#				4	U-Clip Nuts		4	8#	
Install Notes: Overlay $\sqrt{}$ Replacement \times Drill $\sqrt{}$														
Step	Description illustration													
1	Identify the grille & hardware with parts list.													
2	Start by removing the headlamp bolts there are total of three per side.													
3	Remove the turn signal lamp and unplug the lamp socket.													
4	The headlamp has a plastic clip on the bottom push up in order to free the headlamp.													
5	Unplug headlamp bulb socket from the backside.													
6	With the headlamp out of the way remove the corner bolt located in the headlamp area.													
7	Remove the second bolt.													
8	Unplug fog lamp socket.													
9	Remove bolts located on the top side of the bumper.													
10	Remove the front fender splash shield plastic clips located in front of the wheel.													
11	Using a socket wrench remove the corner bolt behind splash shield.(Bolt is in the vertical position)													
12	Remove plastic clips located on the bottom side of the bumper cover.													
13	Bumper cover can now be removed.													
14	Inse	ert grille	into bu	mper openii	ng from the	e fron	t side. Hold	l firml	y in pla	ace and mark m	ounting	tab cente	r holes.	
15	Using 3/16 drill bit drill for mounting screws.													
16	Mounting screw & flat nuts.													
17				he backside	using sup	plied	hardware.							
FOR S														
1	Remove original vent covers and then place the grille in from the front side.													
2	Hold grille firmly in place and mark the screw tab location using a sharp scribe.													
3	Using a 3/16 drill bit. Drill mounting screw hole location.													
4	Note the drilled hole.													
5	Install "U" Nut onto mounting tab.													
6	Fasten mounting screws from the backside.													

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!