

|       |            |             |  |
|-------|------------|-------------|--|
| Part# | GR22FEE06J | Application | <b>For 2003-2007 VW Volkswagen Touareg</b> |
|-------|------------|-------------|--|

| Parts List | Item | Part Name     | QTY | Description     | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-----------------|------|-----------|-----|-------------|
|            | 1    | Billet Grille | 2   | Stainless steel | 3    | Screws    | 6   | #8×2 "      |
|            | 2    | U-Nuts        | 6   | 8#              | 4    | "J" Hooks | 6   | 1"          |

Install Notes: Overlay  Replacement  Drill  Cut

| Step | Description   | illustration   |
|------|---|--|
| 1    | Identify the grille & hardware with parts list.   |  |
| 2    | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.   | N/A  |
| 3    | Center the billet grille over the opening grill shell. fix the "U" nut to the "J" hook let the hole straight.   | N/A  |
| 4    | Hook the shell bar from back, insert the screw into grille welded tab hole insert each tab on the billet insert. Start to thread both screws into the 'J' hooks. Make sure the insert is centered. Tighten the hardware until the billet is held firmly in place. | N/A  |
| 5    | Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.   | N/A  |
| 6    | Reinstall the black plastic cover which was removed in step 2.  | N/A  |
| 7    | Installation completed!!!   | N/A  |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!