




# Grille Installation Instruction

Rev. 180501

|       |              |             |   |
|-------|--------------|-------------|---|
| Part# | GR22GEH16T/H | Application | <b>For 2003-2007 Volkswagen Touareg With Chrome Trim V8</b> |
|-------|--------------|-------------|---|

| Parts List | Item | Part Name   | QTY | Description     | Item | Part Name | QTY | Description |
|------------|------|-------------|-----|-----------------|------|-----------|-----|-------------|
|            | 1    | Mesh Grille | 5   | Stainless steel | 4    | Lock Nut  | 22  | 6-32        |
|            | 2    | Stud        | 16  | 6-32x 1 1/2"    | 5    | Flat Tab  | 6   | /           |
|            | 3    | Stud        | 6   | 6-32x 1"        | 6    | Washer    | 16  | /           |

Install Notes: Overlay  Replacement  Drill  Cut

| Step | Description   | illustration   |
|------|---|--|
| 1    | Identify the grille & hardware with parts list.   |  |
| 2    | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | N/A  |
| 3    | Secure the stud to the threaded holes on the rear of the grille.  | N/A  |
| 4    | Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.                                 | N/A  |
| 5    | Secure grille using the flat tabs and lock nuts and washers from the back side of the OEM grille shell.   | N/A  |
| 6    | Make sure the grille is centered and tighten the fasteners.   |  |
| 7    | Reinstall the black plastic cover which was removed in step 2.  |  |
| 8    | Installation completed!!!   | N/A  |

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!