



# Grille Installation Instruction

Rev. 20220301

<b>Part#</b>	Z65512C&J&S	<b>Application</b>	For 2006-2008 Mercedes-Benz ML350 / ML500 Not For P2 Package (With Oval Fog light)
--------------	-------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	5	Stainless Steel	3	Truss Head Tapping Screws	10	8×1 1/4"
2	Flat Tabs	4			Flat Nuts	10		

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description
------	-------------

Identify the grille & hardware with parts list.

**FOR CENTER BILLET GRILLE:**

1	Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.
2	Place one screw through each of the welded tabs on the billet grille.
3	Place a flat nut over each of the holes on the flat tabs.
4	Place a tab behind the grille shell in line with where the screw comes through. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. <b>DO NOT OVER TIGHTEN SCREWS.</b>

**FOR SIDE BILLET GRILLES:**

1	Drill 3/16" hole on the 10 sites marked on the shell.
2	Tighten grille with Phillips screw and clips provided.
3	Repeat the process on the right opening of the grille shell.
4	Installation completed!!!

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!