


Part#	GR26FEE18A	Application	03~06 Mercedes-Benz E Class – Low Bumper Billet Grille
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Aluminum	3	Screws	8	8#-1 1/4"
	2	"U" nuts	8		4	Flat tabs	8	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Place screws through the welded aluminum tabs on the grille, and insert "U" nut onto the tab let the hole-hole ,	
4	Center billet grille into the opening grille shell.	
5	Place the tab on the end of the screw tight it	
6	Repeat (4) install all for middle billet grille.	
7	Place the side billet grille into the side grille shell, you need to drill hole according to the weld tab' s hole.	
8	Remove the billet grille and drilling	
9	Re-center the billet grille into grille shell install use our screws as above middle grille.(9)Installation is complete.	
10	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!