


Part#	GR26FFE96A/H	Application	For 2007-2011 Mercedes-Benz S550 / S600
-------	--------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Aluminum	4	Truss Head Studs	8	10-24X2"
	2	Flat Washers	8	10#	5	Powder Coated Brackets	8	
	3	K-Lock Nuts	8	10-24				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Attach the fully threaded studs to the backside of the billet grille.	
4	Center the grille into the opening, and then place the powder coated brackets over the studs. Be sure that the grille is still centered, and then secure using the K-lock nuts and washers provided.	
5	Make sure the billet grille is centered and tighten the fasteners.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!