




Grille Installation Instruction

Rev. 190601

| | | | |
|-------|--------------------------|-------------|-----------------------------------|
| Part# | GR26FFF01 A/H | Application | For 2008-2013 Smart Fortwo |
|-------|--------------------------|-------------|-----------------------------------|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-------------|------|----------------|-----|-------------|
| | 1 | Billet Grille | 4 | Aluminum | 2 | Black Bandages | 16 | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|--|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Remove grilles from box and test fit the grilles first to identify the top grille from the bottom grille. They will only fit in one direction correctly. | |
| 3 | Tie the grille and factory shell with black bandages. | |
| 4 | Make sure the billets are centered and tighten the hardware. | |
| 5 | Installation completed!!! | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!