


Part#	GR26IEE18A	<i>Application</i>	For 2003-2006 Mercedes-Benz E Class Not For AMG Sport Package And Avantgarde Trim Level
--------------	------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Stainless steel	4	Plastic Washers	4	
	2	Studs	9	6-32×1"	5	K-Lock Nuts	9	6-32
	3	Washers	5		6	Flat Tabs	5	

Install Notes: **Overlay** **Replacement** **Drill** **Cut**

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Insert grille from front on the opening of factory shell. But you need to drill 3/16" hole in side grille shell, then installing.	
4	Now thread studs into the grille using a slotted screwdriver. Then push the studs through the grid of the shell and center the grille into the opening. Fasten the grille use the plastic washers, the k-lock nuts and washers from the rear, but do not over-tighten.	
5	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!