

# iRunning Board Installation Instruction

**Part#: IB06RJF0**

Rev. 20180501

**Application: For 2000-2006 Toyota Tundra Extended Cab**

**PARTS LIST:**

Item	QTY	Description	Item	QTY	Description
#01	2	Driver Front Mounting Bracket(DFM/PFM)	#06	8	M8 Nylon Lock Nuts
#02	6	Center/Rear Mounting Brackets	#07	16	ST6x25 Self Tapping Screw
#03	8	M8 x1.25-20mm Hex Bolts	#08	16	M6 Square head Bolts
#04	2	Step Board( Driver side & Passenger Side)	#09	16	M6 Flat Washers
#05	16	M8 Flat Washers	#10	16	M6 Nylon Lock Nuts



**DFM/PFM**

**INSTALLATION INSTRUCTION:**

**REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**

1. Drill 5/16" holes in pinch weld as show **(See Fig 1)**.
2. Attach mounting brackets as shown **(See Fig 2,3,4 and 5)**.
3. Insert square head bolts as shown (4 per slot, 8 per board) **(See Fig 6)**.
4. Attach board to brackets as shown. Make sure board and brackets are properly aligned and tighten fasteners. **(See Fig 7)**.
5. Repeat Installation for other side.
6. **INSTALLATION IS COMPLETE!( See Fig 8)**.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For Polished Finishes:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

**For black finishes:** Mild soap may be used to clean the Running Board.

# iRunning Board Installation Instruction

Part#: IB06RJF0

Rev. 20180501

Application: For 2000-2006 Toyota Tundra Extended Cab  
Driver/Left Side Installation Pictured

