

iBoard®

iBoard® by APS


PART#: IB-R111A_B

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

*ROCKER PANEL MOUNT
*NO DRILLING REQUIRED




Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

PART LIST




Customer Support: info@iboardauto.com

iBoard®



STEP 1


Start installation from the Passenger side front of the vehicle. Locate the (3) pairs of factory mounting holes along the pinch weld, (Fig 1).




(Fig 1) Passenger Side Front Mounting Location

STEP 2

Start installation from the passenger side front of the vehicle (Fig 2). Assemble Passenger Front Mounting Bracket (PFM) and Passenger Front Support Bracket (PFS) with (1) M8X1.25-25mm Hex Bolt, (2) M8 Large Flat Washers, (1) M8 Lock Washer and (1) M8 Hex Nut (Fig 3). And then install the Passenger Front Brackets to the rocker panel as shown (Figs 4-5). Don't fully tighten the hardware at this time.




(Fig 2) Passenger Side Front Mounting Location




(Fig 3) Passenger Front Bracket Assembly

iBoard®




(Fig 4) Passenger Side Front Brackets Installation




(Fig 5) Passenger Side Front Brackets Installation

STEP 3


Move to Passenger Side Center & Rear Mounting Locations, (Figs 5 & 6). Repeat **Step 2** to install Passenger Center and Rear Brackets (Figs 7-8). Don't fully tighten the hardware at this time.



(Fig 6) Passenger Side Center Mounting Location



(Fig 7) Passenger Side Rear Mounting Location




(Fig 8) Passenger Side Center Bracket Assembly


iBoard®

STEP 4

- (1) M8X1.25-35mm Hex Bolt
- (1) M8 Lock Washer
- (1) M8 Large Flat Washer




(Fig 9) Passenger Side Center Brackets Installation



(Fig 10) Passenger Side Rear Brackets Assembly

- (1) M8X1.25-35mm Hex Bolt
- (1) M8 Lock Washer
- (1) M8 Large Flat Washer




(Fig 11) Passenger Side Rear Brackets Installation

Select a Running Board. Slip (3) M6x1-20mm Square Head Bolts into each bottom channel (Fig 12). Carefully position the Running Board onto the (3) Mounting Brackets.


IMPORTANT: Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Bracket with (2) M6x1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 Nylon Lock Nuts (Fig 13). Do not fully tighten at this time.

- M6X1-20mm Square Head Bolts



(Fig 12) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

- (2) M6X1-20mm Square Head Bolts
- (2) M6 Large Flat Washers
- (2) M6 Nylon Lock Nuts



(Fig 13) Running Board Installed Onto Mounting Bracket

iBoard®

STEP 5

Level and adjust the Running Board and fully tighten all hardware.

Important: Please follow the recommended Tightening Torques shown in the table on page 1. Don't over tighten, or the nuts/bolts will be damaged.

STEP 6

Repeat **Steps 1-5** for the other side Running Board installation. The installation is completed (**Fig 14**).



(Fig 14) Installation Completed

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.