iBoard®

iBoard® by APS

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

*ROCKER PANEL MOUNT
*NO DRILLING REQUIRED

Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

PART LIST

Front

Driver Front Mounting Bracket (DFM/PFM)

DFM/PFM

Mounting Bracket

iBoard®

 X12
M8 Plastic Washer

 X12
M8 Flat Washer

 X12
M8 Nylon Lock

 X12
M6X1-20mm Square Head Bolt

 X12
M6 Large Flat Washer

 X12
M6X1 Nylon Lock Nut

STEP 1

Start installation from the passenger side front of the vehicle. Locate the Passenger Side Front Mounting Location along the inner side of the body panel, **(Fig 1)**.


(Fig 1) Passenger Side Front Mounting Location

STEP 2

Thread (1) M8 Plastic Washer over each of the (2) factory mounting studs on the body panel, **(Fig 2)**.

IMPORTANT: The M8 Plastic Washers are designed to prevent corrosion between the aluminum body panel and the steel Mounting Brackets.

**Note:** Do not install the Brackets without the Plastic Washers.

(Fig 2) M8 Plastic Washers Installed

STEP 3

Select (1) Passenger Front Mounting Bracket **(DFM/PFM).** Attach the Passenger Front Mounting Bracket to the (2) factory studs with (2) M8 Flat Washers and (2) M8 Nylon Lock Nuts, **(Fig 3).** Do not fully tighten hardware at this time.

(2) M8 Plastic Washers
(2) M8 Flat Washers
(2) M8 Nylon Lock Nuts

(Fig 3) Passenger Front Mounting Bracket (DFM/PFM) Installation

iBoard®

STEP 4

Move to the Passenger Side Center & Rear Locations of the vehicle. Select (2) Mounting Brackets. Repeat **Steps 1—3** to install the passenger side Center & Rear Mounting Brackets. **NOTE:** All (4) Mounting Brackets are universal.

STEP 5

Select a Running Board. Slip (3) M6x1-20mm Square Head Bolts into each bottom channel **(Fig 4)**. Carefully position the Running Board onto the (3) Mounting Brackets.

IMPORTANT: Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Bracket with (2) M6x1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 X1 Nylon Lock Nuts **(Fig 5)**. Do not fully tighten at this time.

M6X1-20mm Square Head Bolts

(Fig 4) Slip (3) M6X1-20mm Square Head Bolts Into Each Bottom Channel

STEP 6

Level and adjust the Running Board and fully tighten all hardware.

(2) M6X1-20mm Square Head Bolts
(2) M6 Large Flat Washers
(2) M6X1 Nylon Lock Nuts

(Fig 5) Running Board Installed Onto Mounting Bracket

STEP 7

Repeat **Steps 1-6** for other side Running Board installation. The installation is completed (**Fig 6**).

(Fig 6) Installation Completed

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.