iBoard®

iBoard® by APS

READ INSTRUCTIONS CAREFULLY BEFORE START ING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

*ROCKER PANEL MOUNT
*NO DRILLING REQUIRED

Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

PART LIST

Front

Mounting Bracket

iBoard®

X6 M8X1.25-25mm Hex Bolt

X6 M8 Flat Washer

X6 M8 Lock Washer

X6 M8 Clip Nut

X6 M10X1.5-25mm Hex Bolt

X12 M10 Flat Washer

X6 M10 Lock Washer

X6 M10 Hex Nut

X12 M6X1-20mm Square Head Bolt

X12 M6 Large Flat Washer

X12 M6X1 Nylon Lock Nut

STEP 1

Start installation from the passenger side of the vehicle. Locate Passenger Side mounting locations as shown on **Fig 1.**

**FORWARD**

(Fig 1) Passenger Side Mounting Locations

STEP 2

Start from the passenger front mounting location. Select (1) M8 Clip Nut. Install M8 Clip Nut as shown, **(Fig 2)**.

FORWARD

M8 Clip Nut

A, B, C

(Fig 2) M8 Clip Nut Installation

STEP 3

Attach (1) Mounting Bracket to the installed M8 Clip Nut and pinch weld with (1) M8X1.25-25mm Hex Bolt, (1) M8 Flat Washer, (1) M8 Lock Washer and (1) M10X1.5-25mm Hex Bolt, (2) M10 Flat Washers, (1) M10 Lock Washer, (1) M10X1.5 Hex Nut, **(Fig 3)**. Do not fully tighten hardware at this time.

Front

(1) M10X1.5-25mm Hex Bolt
(2) M10 Flat Washers
(1) M10 Lock Washer
(1) M10X1.5 Hex Nut

(1) M8X1.25-25mm Hex Bolt
(1) M8 Flat Washer
(1) M8 Lock Washer

(Fig 3) Passenger Front Mounting Bracket Installation

iBoard®

STEP 4

Move to the passenger side center & rear of the vehicle. Select (1) Mounting Bracket. **NOTE:** All (6) Mounting Brackets will fit left or right side. Repeat **Steps 1—3** to install the passenger side Center & Rear Mounting Brackets.

STEP 5

Select a Running Board. Slip (3) M6X1-20mm Square Head Bolts into each bottom channel **(Fig 4)**. Carefully position the Running Board onto the (3) Mounting Brackets.

IMPORTANT: Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Brackets with (2) M6x1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 X1 Nylon Lock Nuts **(Fig 5)**. Do not fully tighten at this time.

M6X1-20mm Square Head Bolts

(Fig 4) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

STEP 6

Level and adjust the Running Board and fully tighten all hardware.

(2) M6X1-20mm Square Head Bolts
(2) M6 Large Flat Washers
(2) M6X1 Nylon Lock Nuts

(Fig 5) Running Board Installed Onto Mounting Bracket

STEP 7

Repeat **Steps 1-6** for the other side Running Board installation. The installation is completed **(Fig 6)**.

(Fig 6) Installation Completed

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.