iBoard®

iBoard® by APS

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

*ROCKER PANEL MOUNT
*NO DRILLING REQUIRED

Fastener Size	Tightening Torque (ft-lbs)
6mm	6-7
8mm	16-18
10mm	31-32
12mm	56-58
14mm	92-94

PART LIST

Front

Driver/Passenger Front
Mounting Bracket (DFM/PFM)

Mounting Bracket

iBoard®

|					
X12 M8X1.25- 30mm Hex Bolt	**X12** M8 Large Flat Washer	**X12** M8 Lock Washer	**X12** M6X1-20mm Square Head Bolt	**X12** M6 Large Flat Washer	**X12** M6X1 Nylon Lock Nut

STEP 1

Start installation from the Passenger side of the vehicle, remove the existing (2) factory bolts on the mounting locations on rocker panel, (**Fig 1 & 2**).


Remove (2) Factory Hex Bolts

Front

(Fig 1) Passenger Side Front Mounting Location

Remove (2) Factory Hex Bolts

(Fig 2) Passenger Side Rear Mounting Location

STEP 2

Select (1) Passenger Front Mounting Bracket **(DFM/PFM).** Attach the bracket over the factory bracket with (2) M8x1.25-30mm Hex Bolts, (2) M8 Large Flat Washers and (2) M8 Lock Washers **(Figs 3)**. Do not fully tighten hardware at this time.

DFM/PFM

Front

(2) M8x1.25-30mm Hex Bolts
(2) M8 Large Flat Washers
(2) M8 Lock Washers

(Fig 3) Passenger Front Mounting Bracket Installed

STEP 3

Move to center & rear mounting locations. Repeat **Steps 1-2** to install the Passenger Center & Rear Mounting Brackets.

**Note: Passenger Center & Rear Mounting Bracket are universal .**

Customer Support: info@iboardauto.com

Rev. 20210201

iBoard®

STEP 4

Select a Running Board. Slip (3) M6x1-20mm Square Head Bolts into each bottom channel **(Fig 3)**. Carefully position the Running Board onto the (3) Mounting Brackets.

IMPORTANT: Do not slide the Running Board on the Brackets or the bottom surface of the board will be damaged. Attach the Running Board to each Mounting Bracket with (2) M6x1-20mm Square Head Bolts, (2) M6 Large Flat Washers and (2) M6 X1 Nylon Lock Nuts **(Fig 4)**. Do not fully tighten at this time.

M6X1-20mm Square Head Bolts

(Fig 3) Slip M6X1-20mm Square Head Bolts Into The Bottom Channels

(2) M6X1-20mm Square Head Bolts
(2) M6 Large Flat Washers
(2) M6X1 Nylon Lock Nuts

(Fig 4) Running Board Installed Onto Mounting Bracket

STEP 5

Level and adjust the Running Board and fully tighten all hardware.

Important: **Please follow the recommended Tightening Torques shown in the table on page 1. Don't over tighten, or the nuts/bolts will be damaged.**

STEP 6

Repeat **Steps 1-5** for the other side Running Board installation. The installation is completed (**Fig 5**).

(Fig 5) Installation Completed

Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

In order to protect your bars/boards, please use only mild soap/non-abrasive products for cleaning.

Customer Support: info@iboardauto.com