


Part#	HT-R31341		Application	For 1997-2006 Jeep Wrangler				
Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Hex Flange Nuts	2	M12X1.75	5	Conical Washers	2	M12
	2	Hex Bolts	2	7/16-14X1¾	6	Carriage Bolts	2	M12X1.75-45
	3	Hex Bolts	2	M12X1.75-50	7	Fishwire	1	
	4	Spacers	2	With SQ Hole				


Gross Load Capacity When Used As A Weight Carrying Hitch: 4000 LBS. Trailer Weight & 400 LBS. Tongue Weight.
*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.*****

- * No Drilling Required
- * No Trimming Required

CONICAL TOOTHED WASHER ORIENTATION DIAGRAM





FISHWIRE TECHNIQUE



NOTE: SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME

REVERSE PULL FISHWIRE TECHNIQUE



The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Part#	HT-R31341	Application	For 1997-2006 Jeep Wrangler
-------	-----------	-------------	-----------------------------

Step	Description
1	Remove existing bolt from rear most hole in the vehicle frame. Note: These bolts hold bumper in place.
2	Fishwire or reverse fishwire the M12 carriage bolts and spacers through access holes and out existing holes in bottom of frame. See Fishwire or Reverse Fishwire Technique. Note: Access hole locations vary by vehicle.
3	Install remaining fasteners into existing weldnuts, as shown. Note: Use of the M12 or 7/16" bolts vary by vehicle.
4	Torque all 7/16" fasteners to 70 lb-ft. Torque all 12mm fasteners to 79 lb-ft.

*****Periodically Check The Receiver Hitch To Ensure That All Fasteners ***
Are Tight & All Structural Components Are Sound.**

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!