



Hitch Installation Instruction


REV.20240901

Part#	HT-X38335	Application	For 2004-2007 Toyota Highlander / 2004-2006 Lexus RX330 / 2006-2008 Lexus RX400H / 2007-2009 Lexus RX350
-------	-----------	-------------	--

Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
HW B (For Hitch Installation)	1#	Hex Bolts	6	M10X1.25-30	2#	Conical Washers	6	M10
HW A (For Hitch Assembly)	3#	Hex Bolts	4	M12X1.75-35	5#	Hex Bolts	4	M12X1.75-45
	4#	Flat Washers	16	M12	6#	Hex Nuts	8	M12X1.75

Gross Load Capacity When Used As A Weight Carrying Hitch:3500 LBS. Trailer Weight & 350 LBS. Tongue Weight.
Gross Load Capacity When Used As A Weight Distribution Hitch:4000 LBS. Trailer Weight & 400 LBS. Tongue Weight.
*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.** ***

Drilling Not Required



The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

REV.20240901

Part#	HT-X38335	Application	For 2004-2007 Toyota Highlander / 2004-2006 Lexus RX330 / 2006-2008 Lexus RX400H / 2007-2009 Lexus RX350
--------------	-----------	--------------------	--

Step	Description
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (4) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (4) M12 Hex Bolts, (8) M12X1.75 Hex Nuts.(Hardware in "HW A").
2	Remove tie down brackets if present.
3	Maneuver passenger side plate around the exhaust and hold hitch up against frame.
4	Align hitch mounting holes to existing weld-nuts in frame. Install M10 bolts and conical washers as shown.
5	Torque M10 fasteners to 47 lb-ft.
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!