



Hitch Installation Instruction


REV. 20240901

Part#	HT-X30182	Application	For 2011-2024 Dodge Durango (Excluding SRT)\ 2012-2021 Jeep Grand Cherokee (Excluding SRT, SRT8 or Trackhawk)\ 2022 Jeep Grand Cherokee WK
-------	-----------	-------------	--


Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
HW A (For Hitch Assembly)	1#	Hex Bolts	8	M12X1.75-35	3#	Hex Flange Nuts	8	M12
	2#	Flat Washers	16	M12				

Gross Load Capacity When Used As A Weight Carrying Hitch: 6000 LBS. Trailer Weight & 600 LBS. Tongue Weight.
Gross Load Capacity When Used As A Weight Distribution Hitch: 7500 LBS. Trailer Weight & 750 LBS. Tongue Weight.
DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.



No Drilling Required



INSTALLED HITCH POSITION



Diesel (DEF) Tank Fastener Locations









The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

REV. 20240901

Part#	HT-X30182	Application	For 2011-2024 Dodge Durango (Excluding SRT)\ 2012-2021 Jeep Grand Cherokee (Excluding SRT, SRT8 or Trackhawk)\ 2022 Jeep Grand Cherokee WK	
Step	Description			
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (8) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (8) M12 Hex Flange Nuts.(Hardware in "HW A").			
2	On diesel models, lower the DEF tank by unclipping the electrical connection on the passenger side and sliding the clips off of the rear studs securing the tank. Using a 13mm socket, remove the two rear stud posts and the two forward hex bolts from the tank, see photos. Note: Do not remove the filler pipe from the DEF tank. The tank should be free to rotate slightly downward on the passenger side for access to the bolts and weld nuts. Due to the diesel exhaust fluid (DEF) tank location, it will need to be lowered to access the passenger side bolts. It is highly recommended that the tank is well supported before removing the fasteners as the tank may weigh as much as 80 lbs.			
				
3	Remove existing M14 bolts. There will be (4) or (6) bolts depending on vehicle model. Retain (4) bolts for hitch installation. Keep the remaining bolts (if any). Note: If there is a factory two loop is present you will need to remove it prior to installation. Trim excess caulk on the vehicle frame rails if it interferes with the hitch installation.			
				
4	Raise the trailer hitch into position and reinstall (4) M14 bolts.			
5	Torque all M14 hardware to 126 ft-lbs. Reinstall DEF tank if lowered on diesel models and reconnect electrical components on STEP 1. Torque DEF tank studs to 21 ft-lbs and the DEF tank Hex Bolts to 24 ft-lbs.			
				
***Periodically Check The Receiver Hitch To Ensure That All Fasteners Are Tight & All Structural Components Are Sound.				

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!