



Hitch Installation Instruction


REV.20240601

Part#	HT-X30206	Application	For 2014-2019 Subaru Outback
-------	-----------	-------------	------------------------------

Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
HW B (For Hitch Installation)	1#	Carriage Bolts	4	M12X1.75-40	3#	Hex Flange Nuts	4	
	2#	Square Spacers	4	M12X1.75	4#	Fishwire	2	
HW A (For Hitch Assembly)	5#	Hex Bolts	8	M12X1.75-35	7#	Hex Flange Nuts	8	M12
	6#	Flat Washers	16	M12				

Gross Load Capacity When Used As A Weight Carrying Hitch:4000 LBS. Trailer Weight & 600 LBS. Tongue Weight.
DO NOT EXCEED VEHICLE MANUFACTURER’S RECOMMENDED TOWING CAPACITY.

Drilling Required
Trimming Required











The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

REV.20240601







Part#	HT-X30206	Application	For 2014-2019 Subaru Outback
Step	Description		
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (8) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (8) M12 Hex Flange Nuts.(Hardware in "HW A").		
2	<p>Lower the exhaust by removing the three rearmost rubber exhaust isolators from the frame mounted hangers.</p> <p>Note: Support the exhaust during installation to prevent damage. See the "Rubber Isolator Removal Diagram".</p> <div><div><p>RUBBER ISOLATOR REMOVAL DIAGRAM</p><p>This technique can be used if exhaust hanger removal pliers are not available.</p><p>Using a 5/8" open end wrench, slide the wrench up to the rubber isolator, cradling the hanger rod as shown.</p><p>Place the flat edge of a pry bar between the wrench and the hanger stop or hanger rod. Then simply rotate the pry bar toward the wrench to remove the rubber isolator.</p><p>Note: Using a lubricant or soapy water on the hanger rod and the rubber isolator helps removal.</p></div></div>		
3	<p>Remove the muffler heat shield and trim it to clear the mounting plate as shown.</p> <div><p>Trim along bend line</p></div>		
4	<p>Remove the two rubber plugs in each frame rail. Enlarge the forward most hole on each frame rail to allow the provided M12 carriage bolt and square -hole spacer to be inserted into the frame rail. See "Hole Enlargement Diagram".</p> <div></div>		
5	<p>Fishwire a M12 carriage bolt and square-hole spacer into the rearmost hole in each frame rail, as shown, leaving the fishwire attached. See "Fishwire Technique".</p> <div><p>FISHWIRE TECHNIQUE</p><p>Insert coiled end of fishwire tool through hitch mounting hole in vehicle frame rail and out the access hole. Pass coiled end of fishwire through spacer and thread bolt into coil. Kink wire to keep spacer separate from bolt as shown. Pull fishwire, spacer and bolt through frame and out mounting hole. Use fishwire to guide hitch during mounting and prevent loss of bolt or spacer inside frame rail.</p></div>		

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

REV.20240601

Part#	HT-X30206	Application	For 2014-2019 Subaru Outback
6	Raise the trailer hitch into position. Center the hitch on the vehicle, remove the fishwire, and loosely secure the hitch to the vehicle with the provided hex flange nuts.		
			
7	Mark and drill the forward most holes in the frame rail using the trailer hitch as your guide. Fishwire a M12 carriage bolt and square-hole spacer into each drilled hole and secure the hitch with a hex flange nut.		
			
8	Torque M12 Carriage Bolt to 58 ft-lbs. Reinstall the heat shield, raise the exhaust back into position and reinstall the rubber isolators.		
			
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.			

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!