




Hitch Installation Instruction

REV.20241201

Part#	HT-X30427	Application	For 2020-2025 Hyundai Palisade All					
Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
HW B (For Hitch Installation)	1#	Hex Bolts	4	M10X1.25-30	4#	Conical Washers	8	M12
	2#	Hex Bolts	4	M12X1.75-120	5#	Conical Washers	4	M10
	3#	Hex Nuts	4	M12X1.75				
HW A (For Hitch Assembly)	6#	Hex Bolts	6	M12X1.75-40	8#	Lock Washers	6	M12
	7#	Flat Washers	10	M12	9#	Hex Nuts	4	M12X1.75

Gross Load Capacity When Used As A Weight Carrying Hitch:5000 LBS. Trailer Weight & 750 LBS. Tongue Weight.
Gross Load Capacity When Used As A Weight Distribution Hitch: 6000 LBS. Trailer Weight & 750 LBS. Tongue Weight
*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. *****









The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

REV.20241201

Part#	HT-X30427	Application	For 2020-2025 Hyundai Palisade All
-------	-----------	-------------	------------------------------------

Step	Description
1	Lower spare tire with 11mm socket and ratchet. Place spare off to the side.
 	
2	Remove the driver side underbody panel by removing (3) push clips and turning (2) plastic retainers counterclockwise with a 14mm socket.
 	
3	Unhook the (4) rearward most exhaust isolators to lower the exhaust. NOTE: be sure to support exhaust.
 	
4	Raise hitch into position over exhaust and loosely install fasteners as shown on page 1.
5	Torque all M12 fasteners to 86 lb-ft and all 10mm fasteners to 47 lb-ft.
6	Reinstall underbody panel, raise spare tire back into position and reinstall the exhaust isolators.
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!