



Hitch Installation Instruction


REV.20240701

Part#	HT-X30596	Application	For 2003-2006 Chevrolet Suburban 1500/2500\ 2003-2006 Chevrolet Avalanche 1500 /2500\ 2003-2006 Chevrolet Tahoe\ 2003-2006 GMC Yukon\2003-2006 Cadillac Escalade /Escalade EXT/ESV
-------	-----------	-------------	--

Hardware List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts	A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
HW B (For Hitch Installation)	1#	Spacers	2	With SQ Hole	4#	Conical Washers	4	M14
	2#	Hex Flange Nuts	2	M12X1.75	5#	Carriage Bolts	2	M12X1.75-45
	3#	Hex Bolts	4	M14X2-40				
HW A (For Hitch Assembly)	6#	Hex Bolts	8	M12X1.75-35	8#		8	M12
	7#	Flat Washers	16	M12				

Gross Load Capacity When Used As A Weight Carrying Hitch: 6000 LBS. Trailer Weight & 600 LBS. Tongue Weight.
Gross Load Capacity When Used As A Weight Distribution Hitch: 10000 LBS. Trailer Weight & 1000 LBS. Tongue Weight.
***DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. ***

- * No Trimming Required
- * No Drilling Required



The instruction here is for your reference only. We strongly recommend the professional installer for best result.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

Part#	HT-X30596	Application	For 2003-2006 Chevrolet Suburban 1500/2500\ 2003-2006 Chevrolet Avalanche 1500 /2500\ 2003-2006 Chevrolet Tahoe\ 2003-2006 GMC Yukon\2003-2006 Cadillac Escalade /Escalade EXT/ESV
-------	-----------	-------------	--

Step	Description
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (8) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (8) M12 Hex Flange Nuts.(Hardware in "HW A").
2	Remove existing M14 bumper bracket bolts from the bottom surface of frame and return to vehicle owner. (Both sides)
3	Raise hitch into position and install fasteners as shown.
4	Torque all M12 fasteners to 58 lb.-ft. Torque all M14 fasteners to 126 lb.-ft.
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!