


PARTS LIST:

| Item | QTY | Description | Item | QTY | Description |
|------|-----|---|------|-----|-------------------------|
| #01 | 1 | Rear Step | #06 | 6 | M12-1.75 Nylon Lock Nut |
| #02 | 1 | Driver/left Frame Mounting Bracket(RDM) | #07 | 4 | M6X1.0 Nylon Lock Nuts |
| #03 | 1 | Passenger/right Frame Mounting Bracket(RPM) | #08 | 4 | M6X1.0 - 20mm T-Bolts |
| #04 | 6 | M12X1.75 - 110mm Hex Bolt | #09 | 4 | M6 Flat Washers |
| #05 | 12 | M12 Flat Washer | | | |



PROCEDURE:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED. LET EXHAUST COOL COMPLETELY BEFORE INSTALLATION.

1. Start the installation under the driver side, rear of the vehicle, **(Figure 1)**. Determine the correct installation for your model.


Models without factory receiver hitch:

- a. Locate the (4) factory holes in the end of the driver side frame channel, **(Figure 1)**. Select the driver side Frame Bracket, **(Figure 2)**. **IMPORTANT:** On models without receiver hitch, install the Bracket on the inside of the frame channel, **(Figure 1)**.
- a. Attach the Frame Bracket to the inside of the frame with the included (3) M12 x 110mm Hex Bolts, (6) M12 Flat Washers and (3) M12 Nylon Lock nuts. Do not fully tighten hardware, **(Figure 2)**.

Models with factory receiver hitch:

- b. Locate the (4) factory hex bolts attaching the receiver hitch to the inside of the driver side frame channel, **(Figure 3)**. Select the passenger side Frame Bracket, **(Figure 4)**. **IMPORTANT:** On models with receiver hitch, the Brackets will be flipped side to side so the passenger side Bracket will be installed on the outside of the driver side frame channel to clear the hitch, **(Figure 4)**.


Driver/left Side Installation Pictured



(Fig 5) Passenger side Bracket installed on outside of driver side frame channel (models with hitch only)



(Fig 6) Slip M6 T-bolts into the bottom channel



(Fig 7) Bracket Installation