


PARTS LIST:

2	P1 Running Boards (78in)	2	10mm x 40mm Short Bolt Plates (rear use)
1	Driver/Left Front Mounting Bracket	4	10mm Plastic Retainers
1	Passenger/Right Front Mounting Bracket	2	10-1.5mm x 80mm Hex Bolts
1	Driver/Left Front Support Bracket	14	10mm x 27mm x 3mm Flat Washers
1	Passenger/Right Front Support Bracket	2	10mm x 20mm x 2mm Flat Washers
1	Driver/Left Center Mounting Bracket	16	10mm Lock Washers
1	Passenger/Right Center Mounting Bracket	16	10mm Hex Nuts
1	Driver/Left Center Support Bracket	2	8mm x 35mm Hex Bolts
1	Passenger/Right Center Support Bracket	6	8mm x 25mm Hex Bolts
1	Driver/Left Rear Mounting Bracket	14	8mm x 24mm x 2mm Flat Washers
1	Passenger/Right Rear Mounting Bracket	8	8mm Lock Washers
1	Driver/Left Rear Support Bracket	6	8mm Hex Nuts
1	Passenger/Right Rear Support Bracket	2	8mm Nut Plates
2	Center Support Pads	12	6mm x 22mm x 2mm Flat Washers
6	6mm Double Bolt Plates	12	6mm Lock Washers
10	10mm Spiral Bolts	12	6mm Hex Nuts
2	10mm x 40mm Long Bolt Plates (front use)	2	Fish Wires



PROCEDURE:


1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. CUTTING IS REQUIRED.
2. Starting from under the passenger/right side of the vehicle, locate the rectangular clips attaching the plastic rocker cover to the bottom of the body. Remove the second clip back from the front wheel opening, (**Figures 1 & 2**). Select (1) "S" Spiral Bolt. Insert the unthreaded end of the Bolt into the hole in the rocker panel, (**Figure 3**). Select the passenger/right front Support Bracket. Attach the Support

Bracket to the “S” Bolt with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Figure 4)**. Snug but do not fully tighten hardware.

3. Hold the passenger/right front Mounting Bracket up to the bottom of the body, **(Figure 5)**. Line up the outer hole in the Bracket with the hole in the Support Bracket. Line up the inner end of the Mounting Bracket with the oval hole in the floor. Use a marker or masking tape to trace the outline of the Mounting Bracket onto the plastic cover, **(Figure 6)**.
4. Move to the center mounting location below where the front and rear doors meet, **(Figure 7)**. Remove the (2) rectangular plastic clips.
For Non-Hybrid Models: Insert (2) Spiral Bolts into the holes. Attach the passenger/right Center Support Bracket to the Spiral Bolts with (2) 10mm Flat Washers, (2) 10mm Lock Washers and (2) 10mm Hex Nuts, **(Figure 8A)**. Snug but do not fully tighten hardware.
For Hybrid Models: Insert (2) Nut Plates into the holes. Attach the passenger/right Center Support Bracket to the Nut Plates with (2) 8mm Flat Washers, (2) 8mm Lock Washers and (2) 8mm Hex Bolts, **(Figure 8B)**. Snug but do not fully tighten hardware.
5. Select (1) 10mm x 80mm Hex Bolt, (1) 10mm Hex Nut, (1) 10mm Lock Washer and (1) 10mm Small Flat Washer, **(Figure 9)**. Thread the Hex Nut onto the Long Bolt. Slide the Lock Washer then the Flat Washer onto the Bolt. Thread the Bolt and Washers up and into the inner end on the center Mounting Bracket, **(Figure 9)**. Hold the passenger/right center Mounting Bracket up to the bottom of the body. Line up the outer hole in the Bracket with the hole in the Support Bracket. Place (1) Center Support Pad onto the end of the Hex Bolt, **(Figure 9)**. Use a marker or masking tape to trace the outline of the Support Pad onto the plastic cover, **(Figures 10 & 11)**.
6. Continue along the passenger/right side to the last two clips, **(Figure 12)**. Insert (2) “S” Bolts into the holes. Attach the passenger/right Rear Support Bracket to the “S” Bolts with (2) 10mm Flat Washers, (2) 10mm Lock Washers and (2) 10mm Hex Nuts, **(Figure 13)**.
7. Hold the passenger/right rear Mounting Bracket up to the bottom of the body. Line up the outer hole in the Bracket with the hole in the Support Bracket. Line up the inner end of the Mounting Bracket with the hole in the floor. Use a marker or masking tape to trace the outline of the Mounting Bracket onto the plastic cover.
8. Remove the plastic cover from the bottom of the body. Use a hacksaw blade or sharp knife to cut out the marked areas. Once cut, partially reinstall the cover. Leave the front and rear of the cover loose.
9. Move to the front mounting location. Select the 10mm “Long” Bolt Plate, **(Figure 14)**. Insert the Bolt Plate into the oval hole in the floor, **(Figure 15)**. Thread (1) 10mm Plastic Retainer onto the Bolt Plate to help hold in place. Use is not mandatory for installation. Attach the passenger/right front Mounting Bracket to the Bolt Plate with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Figure 16)**. Attach the Mounting Bracket to the front facing side of the Support Bracket with the included (1) 8mm x 25mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, **(Figure 16)**. Do not fully tighten hardware.
10. Move to the center mounting location. Attach the Center Mounting Bracket to the rear facing side of the Center Support Bracket with the included (1) 8mm x 25mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, **(Figure 17)**. Tighten or loosen the long 10mm Hex Bolt with Center Support Pad until the Mounting Bracket is close to level and in line with the front and rear Brackets. Leave hardware loose.
11. Continue to the rear mounting location. Thread (1) 10mm Fish Wire onto (1) 10mm “Short” Bolt Plate, **(Figure 18)**. Insert Fish Wire and (1) 10mm “Short” Bolt Plate into the square hole and down through the round hole in the floor, **(Figures 19 & 20)**. Thread (1) 10mm Plastic Retainer onto the Bolt Plate to help hold in place. Use is not mandatory for installation. Attach the passenger/right Rear Mounting Bracket to the Bolt Plate with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Figure 21)**. Attach the Mounting Bracket to the rear facing side of the Support Bracket with the included (1) 8mm x 25mm Hex Bolt, (2) 8mm Flat Washers, (1) 8mm Lock Washer and (1) 8mm Hex Nut, **(Figure 21)**. Do not fully tighten hardware.
12. Carefully unwrap and select (1) Running Board. Place the Running Board on top of the Brackets. Locate the channels in the bottom of the Running Board. Select (3) 6mm Double Bolt Plates, **(Figure**

- 22).** Insert the Bolt Plates into the channels in the bottom of the Running Board closest to the Brackets. Lift the Running Board up and guide the studs through the Brackets.
- 13.** Attach the Running Board to the Brackets with (6) 6mm Flat Washers, (6) 6mm Lock Washers and (6) 6mm Hex Nuts, **(Figure 23)**. **NOTE:** The Running Board is designed to fit close to the vehicle. It may be necessary to loosen the Bracket hardware slightly and tilt the Brackets downward to insert the Running Board between the Brackets and the body.
- 14.** Level and adjust the Running Board as necessary and fully tighten all hardware attaching front and rear brackets only.
- 15.** Move to the center Mounting Bracket. Thread the 10mm Hex Bolt in or out to adjust the Bracket up to the Running Board, **(Figure 9)**. Once properly adjusted, turn the Hex Bolt in (clockwise) 1/4-1/2 of a turn then tighten the 10mm Hex Nut on the Bolt against the Bracket to lock in place. Fully tighten all Center Bracket hardware.
- 16.** Fully reattach plastic cover to floor.
- 17.** Repeat **Steps 2—16** for driver/left Running Board installation.
- 18.** Do periodic inspections to the installation to make sure that all hardware is secure and tight.
- To protect your investment,** Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used to clean the Running Boards.


Passenger/right Side Installation Pictured




(Fig 1) Passenger/right front mounting location, remove clip (arrow)



(Fig 2) Passenger/right #2 clip removed




(Fig 3) Insert "S" Spiral Bolt into opening after removing clip (arrow)




(Fig 4) Attach passenger/right front Support Bracket to Spiral Bolt


Passenger/right Side Installation Pictured



(Fig 5) Hold passenger/right front Bracket in place. Trace outline of Bracket onto cover




(Fig 6) Trace outline of passenger/right front Bracket onto cover



(2) "S" Spiral Bolts


(2) 10mm Flat Washers
 (2) 10mm Lock Washers
 (2) 10mm Hex Nuts

(Fig 7) Passenger/right center mounting location. Remove clips, insert Spiral Bolts. For Hybrid Models, insert (2) 8mm Nut Plates instead of the Spiral Bolts




(Fig 8A) Attach passenger/right center Support Bracket to Spiral Bolts

(2) 8mm Flat Washers
 (2) 8mm Lock Washers
 (2) 8mm Hex Bolts




(Fig 8B) For Hybrid Models, attach passenger/right center Support Bracket the Nut Plates




10mmx 80mm Hex Bolt
 10mm Hex Nut
 10mm Lock Washer
 10mm Small Flat Washer

(Fig 9) Assemble passenger/right Center Mounting Bracket with Support Pad


Passenger/right Side Installation Pictured



(Fig 10) Trace outline of passenger/right center Bracket Support Pad onto cover




(Fig 11) Trace outline of passenger/right center Bracket Support Pad onto cover




(Fig 12) Passenger/right rear mounting location. Remove clips, insert "S" Bolts

- (2) 10mm Flat Washers
- (2) 10mm Lock Washers
- (2) 10mm Hex Nuts



(Fig 13) Attach passenger/right Rear Support Bracket to "S" Bolts




(Fig 14) Long and Short Bolt Plates with Plastic Retainers (retainer use optional)

Passenger/right Side Installation Pictured




(Fig 15) Insert "Long" Bolt Plate into oval hole in front floor location (arrow)

- 8mm x 25mm Hex Bolt
 - (2) 8mm Flat Washers
 - 8mm Lock Washer
 - 8mm Hex Nut
- 10mm Long Bolt Plate
 - 10mm Plastic Retainer
 - 10mm Flat Washer
 - 10mm Lock Washer
 - 10mm Hex Nut



(Fig 16) Attach passenger/right Mounting Bracket to Bolt Plate and front of Support Bracket




(Fig 17) Attach passenger/right center Mounting Bracket to back of Support Bracket

- 8mm x 25mm Hex Bolt
- (2) 8mm Flat Washers
- 8mm Lock Washer
- 8mm Hex Nut




(Fig 19) Insert "Short" Bolt Plate into square hole and down through floor (arrow)



(Fig 18) Thread (1) 10mm Fish Wire onto (1) 10mm "Short" Bolt Plate


Passenger/right Side Installation Pictured



(Fig 20) "Short" Bolt Plate installed (arrow)


- 10mm Short Bolt Plate
- 10mm Plastic Retainer
- 10mm Flat Washer
- 10mm Lock Washer
- 10mm Hex Nut

- 8mm x 25mm Hex Bolt
- (2) 8mm Flat Washers
- 8mm Lock Washer
- 8mm Hex Nut




(Fig 21) Attach passenger/right rear Mounting Bracket to Bolt Plate and back of Support Bracket

- Insert 6mm Double Bolt Plate



(Fig 22) Slide 6mm Double Bolt Plates into track on bottom of Running Board

- (2) 6mm Flat Washers
- (2) 6mm Lock Washers
- (2) 6mm Hex Nuts



(Fig 23) Attach Running Board to the (3) Mounting Brackets (passenger/right front installation illustrated)